

Model: LV110WP

levoit

Water Filter Pitcher

Questions or Concerns?

Please contact us Mon–Fri, 9:00 am–5:00 pm PST/PDT
at support@levoit.com or at **(888) 726-8520**.

READ AND SAVE THESE INSTRUCTIONS

THANK YOU FOR PURCHASING THE WATER FILTER PITCHER BY LEVOIT.

If you have any questions or concerns,
please reach out to us at support@levoit.com.
We hope you enjoy your new pitcher!

FIND US ONLINE

Search for [@LevoitLifestyle](#) • [#LevoitLove](#) • [#LevoitLifestyle](#)
on social media for tips, special deals, giveaways, inspiration,
and more.

TABLE OF CONTENTS

Package Contents	4
Safety Information	5
Getting to Know Your Pitcher	6
Getting Started	7
• Restrictor Cap Settings	7
• Rubber Gasket	8
Using Your Pitcher	9
Filter Details	9
Filter Change Indicator	10
Care & Maintenance	11
Troubleshooting	12
Warranty Information	12
Customer Support	14

PACKAGE CONTENTS

1 x Water Filter Pitcher
1 x Filter Cartridge
1 x User Manual


SAFETY INFORMATION

Follow all safety guidelines. Read all instructions before using.

- **Do not** use until all water has been filtered, to avoid pouring out unfiltered water.
- **Only** filter tap water. This pitcher is not designed to filter water from other sources (such as river water).
- The filter cartridge may become clogged and may not work correctly if filtering liquids other than tap water.
- **Do not** filter hot water (over 95°F / 35°C). This may damage the filter and may release contaminants.
- Use filtered water within 1–2 days. Bacteria may grow in the water if left longer.
- Keep the pitcher closed, and store in the refrigerator when not using.
- **Do not** expose the pitcher to direct sunlight.

GETTING TO KNOW YOUR PITCHER

Your water pitcher filters out chlorine and impurities in your water to improve taste and smell, reduce water hardness, and protect your health. The pitcher can hold up to 2.5 liters / 10 US cups. All pitcher materials are food-grade plastic.



- A. Lid
- B. Water Inlet
- C. Filter Change Indicator
- D. Filter Chamber
- E. Water Outlet
- F. Pitcher
- G. Handle
- H. Filter Cartridge
- I. Filter Restrictor Caps

GETTING STARTED

1. Remove all packaging from the water pitcher and filter cartridge.
2. Remove the restrictor caps from the bottom of the filter. [Figure 1.1]
4. Rinse the filter cartridge thoroughly for 10 seconds under running water.
5. Replace the restrictor caps on the bottom of the filter.




Figure 1.1

3. Soak the filter cartridge in clean tap water (submerged completely) for 15 minutes.

NOTE: There may be carbon dust in the water while rinsing or soaking the filter. This is normal.

Restrictor Cap Settings

- Place the restrictor cap in the “+” position if you want water to filter faster, or in the “-” position if you want water to filter more thoroughly. [Figure 1.2]




Figure 1.2

GETTING STARTED (CONT.)

- You can remove the caps completely if you want water to filter as fast as possible.

Rubber Gasket

- Make sure the rubber gasket is correctly in place on the filter cartridge. If the rubber gasket has come loose, press into place, making sure the ridge is facing up. [Figure 1.3]




Figure 1.3

- Place the filter cartridge into the filter chamber. Press the cartridge into place as firmly as possible to prevent leaks. [Figure 1.4]
- Fill the pitcher with cold tap water. Discard the filtered water. Refill and discard the water two more times.
- Reset the filter indicator (see **Filter Change Indicator**, page 10). Your filter is ready to use.





Figure 1.4

NOTE: If water filtration becomes slow, repeat these steps again. Shake the filter before replacing it into the pitcher.

USING YOUR PITCHER

- Fill the filter chamber with cold tap water.
- Allow all water to filter into the pitcher before pouring.



FILTER DETAILS

A. Upper Micro Net

- Removes particles suspended in the water, such as sand, rust, sludge, and organic matter.

B. Activated Carbon

- Uses high-quality activated carbon for excellent filtration.
- Removes chlorine taste and odor effectively.
- Removes pesticides (including Endrin) and residual pollutants.
- Improves taste of water.


C. Ion-Exchange Resin

- Reduces heavy metals (such as lead, cadmium, mercury, copper, and aluminum).
- Reduces minerals in water to soften it, leaving a percentage of beneficial minerals behind (such as calcium and magnesium).

D. Lower Micro Net

- Final filtration removes remaining unwanted particles in the water.

FILTER CHANGE INDICATOR



- The lid has a timer and indicator to remind you to change the filter. Changing the filter is important to keep your water purified.
 - The filter cartridge should be replaced after 60 days, or after filtering 150 L / 40 US gal of water.
1. Press and hold **START** for 3 seconds or until the display turns on.
 2. Use the indicator as a reminder to replace the filters. The number at the top shows the days remaining until you need to change the filter,

and the 4 bars show the remaining percentage of filter life (100%, 75%, 50%, and 25%).

3. Replace the filter when the number of days reads "0". All display bars will reappear and blink.
4. To reset the filter timer, press **START** firmly for 8 seconds. The indicator will stop blinking, and will reset. Remember to reset the indicator after replacing the filter.
5. To pause the filter timer and hide the filter indicator display, press and hold **START** for 3 seconds. Release the **START** button. The display will go blank and the timer will be paused.

NOTE: Pause the filter timer when you won't be using your water pitcher for a long period of time. Remember to resume the filter timer when you start using your water pitcher again.

FILTER CHANGE INDICATOR (CONT.)

6. To resume the filter timer and show the display, press and hold **START** again for 3 seconds.

NOTE:

- *The filter cartridge cannot be cleaned, only replaced.*
- **Only** use *Levoit LV110WP-RF replacement filter cartridges for this pitcher.*
- *To buy replacement filters, visit Levoit's online store. Go to levoit.com for more information.*

CARE & MAINTENANCE

NOTE: Do not immerse the timer in water or place under running water.

- Clean the pitcher regularly.
- Wash all parts except the timer and filter with mild detergent and a soft cloth, then rinse thoroughly. **Do not** use abrasive cleaners. **Do not** expose the filter to detergent.
- If necessary, wipe the timer with a wet cloth.
- When storing the pitcher for a long period of time, remove the filter from the pitcher and store separately.

NOTE: If water takes an unusually long time to filter, the filter cartridge may have air trapped in it. Take the filter out and shake it, then place the filter back into the pitcher.

TROUBLESHOOTING

Problem	Possible Solution
Water filtration is too slow.	Place the restrictor cap in the "+" position if you want water to filter faster, or remove the caps completely if you want water to filter as fast as possible (see page 7).
	Follow the steps in Getting Started (see page 7) to soak the filter. Shake the filter before replacing it into the pitcher. Press the cartridge into place as firmly as possible to prevent leaks.

WARRANTY INFORMATION

Product Name	Water Filter Pitcher
Model	LV110WP
Default Warranty Period	1 year
<i>For your own reference, we strongly recommend that you record your order ID and date of purchase.</i>	
Order ID	
Date of Purchase	

TERMS & POLICY

Arovast Corporation warrants all products to be of the highest quality in material, craftsmanship, and service, effective from the date of purchase to the end of the warranty period.

Arovast Corporation will replace any product found to be defective due to manufacturer flaws based on eligibility. Refunds are available within the first 30 days of purchase. Refunds are only available to the original purchaser of the product. This warranty extends only to personal use and does not extend to any product that has been used

for commercial, rental, or any other use in which the product is not intended for. There are no warranties other than the warranties expressly set forth with each product.

This warranty is non-transferrable. Arovast Corporation is not responsible in any way for any damages, losses, or inconveniences caused by equipment failure or by user negligence, abuse, or use noncompliant with the user manual or any additional safety or use warnings included in the product packaging and manual.

This warranty does not apply to the following:

- Damage due to abuse, accident, alteration, misuse, tampering, or vandalism.
- Improper or inadequate maintenance.
- Damage in return transit.
- Unsupervised use by children under 18 years of age.

Arovast Corporation and its subsidiaries assume no liability for damage caused by the use of the product other than for its intended use or as instructed in the user manual. Some states do not allow this exclusion or limitation of incidental or consequential losses so the foregoing disclaimer may not apply to you. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

ALL EXPRESSED AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Extend Your Warranty by 1 Year

Register your product at www.levoit.com/warranty to extend your 1-year warranty by an additional year.

Please fill out all required fields and include your order ID, place of purchase, and purchase date, if applicable.

Defective Products & Returns

If you discover your product is defective within the specified warranty period, please contact Customer Support via support@levoit.com with a copy of your invoice and order ID. **DO NOT** dispose of your product before contacting us. Once Customer Support has approved your request, please return the product with a copy of the invoice or order ID.

CUSTOMER SUPPORT

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

Arovast Corporation

1202 N. Miller St., Suite A
Anaheim, CA 92806

Email: support@levoit.com

Toll-Free: (888) 726-8520

Support Hours

Mon–Fri, 9:00 am–5:00 pm PST/PDT

**Please have your order invoice and order ID ready before contacting Customer Support.*

Connect with us @LevoitLifestyle



lëvoit

levoit.com

JJ0719CY-M1.1_0719LV110WP