



---

# Big Shot 2-Player Basketball



**Please keep this instruction manual for future reference**

**If you have any problems with your new product,  
please contact Triumph Sports USA at 1-866-815-4173,  
or e-mail us at [csr@triumphsportsusa.com](mailto:csr@triumphsportsusa.com)  
for any technical support or warranty issues.**

# Limited 90-Day Triumph Sports USA, Inc. Warranty

All Triumph Sports USA, Inc. (TSU) games have a limited 90-day from date of purchase warranty. This warrants the retail purchaser for any TSU game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. The only exceptions to the warranty include main frames, tabletops, playing surfaces, batteries or tools. Damaged main frames, tabletops, playing surfaces need to be returned to the store as we are unable to replace these parts. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the TSU game. This will void any and all TSU warranties.

**A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by email, in writing or by contacting our Customer Service Department at: 1-866-815-4173 or email us at [csr@triumphsportsusa.com](mailto:csr@triumphsportsusa.com).**

## Warnings



**WARNING:** Choking Hazard--Toy contains small balls and/or small parts.  
Not for children under 3 years of age.

**Be sure to check out all the exciting games**  **has to offer. Visit our web site at:**

[www.triumphsportsusa.com](http://www.triumphsportsusa.com)



**BILLIARDS**



**DARTS**



**GAME TABLES**



**CASINO**



**OUTDOOR GAMES**










































**DARTBOARDS**

Triumph Sports USA  
11327 W Lincoln Ave.  
West Allis, WI 53227




[www.triumphsportsusa.com](http://www.triumphsportsusa.com)

©2013 Triumph Sports USA. All Rights Reserved.

# Parts List

1  Board L Tube 2pcs	2  Board Tube 2pcs	3  Left Tube 1pc	4  Right Tube 1pc	5  Horizontal Frame Brace U Tube 1pc
6  Left Mounting Tube 1pc	7  Support Tube 2pcs	8  Right Mounting Tube 1pc	9  Ramp Tube 2pcs	10  Ramp L Tube 2pcs
11  Ramp U Tube 1pc	12  Horizontal Tube 2pc	13  Ball Ramp with Side Netting 1pc	14  Electronic Scorer 1pc	15  Paddle with Sensor 2pcs
16  Control Box with Control Wire 1pc	17  Rim 2pcs	18  Rim Support Plate 2pcs	19  Inflation Pump With Needle 1pc	20  Net 2pcs
21  Backboard 1pc	22  M6 x 1mm washer 4pcs	23  M6 x 20mm Bolt 16pcs	24  M6 x 50mm Bolt 6pcs	25  M6 x 55mm Bolt 4pcs
26  M6 x 65mm Bolt 4pcs	27  M6 Nut 32pcs	28  Basketball 4pcs	29  3.5 x 10mm Bolt 4pcs	30  Electronic Scorer Face Plate 1pc
31  Wrench 1pc	32  M6 x 92mm Bolt 2pcs	33  Lock Pin 2pcs	34  Adaptor 1pc	35  Scoring Arm Plate 2pcs
36  Allen Key 1pc	37  Scorer Control Wire 1pc	38  Plastic Bolt 1pc	39  M6 x 2mm washer 2pcs	

# PRE-INSTALLED PARTS

<b>P1</b>  Plastic Pole insert-A 2pcs	<b>P2</b>  Plastic Pole insert-B 8pcs	<b>P3</b>  Spring Lock 8pcs
--	--	---



## WARNING:

- 1) Requires 3 AA Batteries (Not included).
- 2) Do not mix old and new batteries.
- 3) Do not mix alkaline, standard (carbon zinc), or rechargeable (nickel-cadmium) batteries.

## Assembly Instructions

Find a clean, level place to begin the assembly of your Basketball Game. We recommend that two adults work together to assembly this basketball game.

Remove all the parts from the box and verify that you have all of the listed parts as shown on the Parts List. Carefully cut or tear the four corners of the box so that the bottom of the box can be used as your work surface.

### FIG. 1 & 2

Attach the Board Tubes (#2) to the Left Tube (#3) and Right Tube (#4) using spring lock as shown in FIG.1.

Attach the Support Tubes (#7) to the Mounting Tube (#6) and (#8) using spring lock as shown in FIG.2.

FIG.1





FIG.2






## FIG. 3

### FIG. 3A

Attach the Horizontal Frame Brace U Tube (#5) to the Left Vertical Support Tube (#3) and Right Vertical Support Tube (#4) using Bolts (#26) and Nuts (#27) as shown in FIG. 3A.

**Important:** Tubes #2 and #3 when assembled must be attached to the left side of the Horizontal Frame Brace U Tube (#5). Tubes #2 and #4 when assembled must be attached to the right side of the Horizontal Frame Brace U Tube (#5).



### FIG. 3B

Attach the Left Mounting Tube (#6) and Right Mounting Tube (#8) to the Horizontal Frame Brace U Tube (#5), with Bolts (#26) and Nuts (#27) as shown in FIG. 3B.


**Attention:** Be careful not to reverse the left and right Mounting Tubes.

### FIG. 3C

Attach the Support Tubes (#7) to the Board Tubes (#2), with Bolts (#24) and Nuts (#27). As shown in FIG. 3C.


### FIG. 4

Attach the Horizontal Tube (#12) to the Board Tubes (#2) using Bolts (#24) and Nuts (#27) as shown in FIG. 4. Then insert the Board L Tubes (#1) into the Board Tubes (#2) as shown in FIG. 4.




## FIG. 5

Attach the Ramp Tubes (#9) to the Left Mounting Tube (#6) and Right Mounting Tube (#8) using Bolts (#32), Washers (#22), Washers (#39), Lock Pin loop (#33) and Nuts (#27) as shown in FIG.5. Now insert the Lock Pins (#33) into the pivot joint to lock the game into playing position.




## FIG. 6

Attach the Ramp L Tubes (#10) to the Ramp Tube (#9) using spring lock as shown in FIG.6.




**FIG. 7**

Attach the Rim Assemblies (#17) and Rim Support Plates (#18) to the Backboard (#21) using the Bolts (#23), and Nuts (#27). Then attach the Paddle with Sensors (#15) and the Scoring Arm Plates (#35) to the Backboard (#21) using the Bolts (#23), and Nuts (#27) as shown in FIG. 7



**FIG. 8**




Attach Electronic Scorer Face Plate(#30) to Backboard (#21) and connect with the Electronic Scorer(#14) using Bolts (#29) as shown in FIG.8.



**FIG. 8A**

Loop the Nets (#20) through the Net Hooks on the Rims (#17) as shown in FIG. 8A

**FIG. 8A**



## FIG. 9

### FIG. 9A & 9B

Slide elastic straps and the sleeve of the Ball Ramp with Side Netting (#13) onto the Board L Tubes as shown in FIG. 9A & 9B.

### FIG. 9C

Slide the Front Ramp U Tube (#11) into the upper sleeve of the Ball Return Netting (#13) as shown in FIG. 9C.

### FIG. 9D


Attach the Front Horizontal Ramp U Tube (#11) to the Front Ramp L Tube (#10) using the spring lock as shown in FIG. 9D.

### FIG. 9E

Place the Horizontal Tube (#12) over the lower sleeve of the Ball Return Netting (#13). And then attach it to the Front Horizontal Ramp U Tube (#11) using Bolts (#24) and Nuts (#27) as shown in FIG. 9E.



### FIG. 10

With the help of another adult, Attach the Backboard (#21) to the Board L Tubes (#1) using Bolts (#25), Washers (#22) and Nuts (#27) as shown in FIG. 10A. At each bottom hole of the backboard, attach the ramp tabs of Ball Return with Netting (#13) using Bolts (#25), Washers (#22) and Nuts (#27) as shown in FIG. 10B.



## FIG. 11


Connect the Sensor Wire of Paddle to the Electronic Scorer (#14) as shown in FIG.11. Connect the Control Wire to the Electronic Scorer (#14) as shown in FIG.11 and 11A. This game has a Dual Power feature. You can insert 3 AA Batteries into the battery compartment on the back of the Electronic Scorer (#14) or use the A/C Adaptor when your game is close to a power source. Please remove the batteries when you are using the A/C Adaptor.



## FIG. 12

Now attach the Control Box (#16) to the corner of the Ramp U Tube (#11) using the plastic bolt (#38) as shown in FIG.12A.

Run the rest of the Control Wire (#37) through the loops on the Ball Return with Side Netting (#13). Place the Control Wire on the Ramp U Tube (#11) using the Self - Stick Straps.




## FIG. 13

To fold the basketball game into the storage position, remove the Lock Pins (#33) from the playing position on the Mounting Tubes (#6) & (#8). Lift the Front Horizontal Ramp Support Tube (#11) until the game is in the storage position as shown in FIG. 13


## FIG. 13A

Insert the Lock Pins (#33) back into the Mounting Tubes (#6) & (#8), locking the basketball game into the storage position.



## ELECTRONIC SCORER OPERATION

Unscrew bolt using a screwdriver and open the battery box. Insert 3 AA batteries (not included) in the order of polarity as shown on the inside cover. Then close the cover using a screwdriver. Turn the power ON using the ON/OFF switch. (if the game will not be used for a long period of the time, we recommend that the batteries should be removed).



## CONTROL BOX OPERATION

Press "ON/OFF" to activate the scorer.

Scoreboard "HOME" shows "01" (pre-set game 1).

Press "SELECT UP and DOWN" to select a game.

Press "SELECT UP and DOWN" to enter selected game mode.


Press "SOUND" to switch sound ON/OFF while playing.

Press "PAUSE" to pause or start time counting.

Press and hold the button "ON/OFF" 3 seconds to turn off scorer.

Press and hold the button "RESET" 3 seconds to reset the games.

Note: If no shot is made or no button is pressed in 15 minutes, scorer will be turned off automatically.



# Trouble Shooting:

## Game won't turn on

1. Make sure switch on scorer is in the on position.
2. Make sure switch paddle wires are in the home and visitor slots on the scorer.
3. Make sure the control box wire is in the control slot on the scorer.
4. Press/hold down the on/off bottom on the scorer for 2 seconds to turn game on.

## Game shuts off during play

1. Check the batteries. Make sure they are new batteries.
2. The batteries might be loose causing the game to shut off. Take off the battery cover on the scorer. Take a piece of paper, fold it so it fits over the batteries. Put the battery cover back on. This should better secure the batteries and prevent them from being moving in any way.

# Game Options

## Beat the time Clock

Press "PLAY" to enter game 1.  
Press "UP/Down" to select single/multiple players (P1/P2/P3/P4).  
Press "PLAY" after the number of player is selected.  
Press "UP/Down" to select playing time, 30/45/60 seconds.  
Press "PLAY" to begin the game.  
Scoreboard "HOME" shows Player 1, 3; Scoreboard "VISITOR" shows Player 2, 4.  
All shots worth 2 points until last 10 seconds, each score counts 3 points.  
Countdown 5 seconds to next player's turn when one player finishes game.  
Player with more points scored wins ( LED will flash on player with higher score).  
Press "PLAY" to restart this game.

## 3 Point Beat the Time Clock

Press "PLAY" to enter game 2.  
Press "UP/Down" to select single/multiple players (P1/P2/P3/P4).  
Press "PLAY" after the number of player is selected.  
Press "UP/Down" to select playing time, 30/45/60 seconds.  
Press "PLAY" to begin the game.  
Scoreboard "HOME" shows Player 1, 3; Scoreboard "VISITOR" shows Player 2, 4.  
All shots made count 3 points.  
Countdown 5 seconds to next player's turn when one player finishes game.  
Player with more points scored wins ( LED will flash on player with higher score).  
Press "PLAY" to restart this game.

## Battle Back

Press "PLAY" to enter game 3.  
Press "UP/Down" to select playing time, 30/45/60 seconds.  
Press "PLAY" to begin the game.  
Shot made in "HOME" frame, +2 points scored display on "HOME" board and -2 points for "VISITOR".  
Shot made in "VISITOR" frame, +2 points scored display on "VISITOR" board and -2 points for "HOME".  
Once a player scores 10 points who wins and game is finished.  
Press "PLAY" to restart this game.

## Horse

Press "PLAY" to enter game. Press "UP/Down" to select multiple players (P2/P3/P4).

Press "PLAY" after the number of player is selected.

Player has to make a shot in 2 seconds.

First player is allowed to shoot at any hoop (Home or VISITOR). If first player scores in 2 seconds, no letter is given. Game continues for next player. Scoreboard will display "next player(P2P3/P4)" and LED will flash twice in a second. After flash, next player has to duplicate the shot in the same hoop selected by first player.

If player can't score in 2 seconds, player receives the first letter "H" which will display on scoreboard. Game remains for the same player until the player scores. If player keeps missing, player receives "O" followed by "R", "S", "E". The letter "E" is given, the player is out.

The first player to spell "horse" loses. Players stay in repeat step d.e.f. till game is finished.

The last player to spell "horse" wins. Press "PLAY" to restart this game.

## Check Point

Press "PLAY" to enter game 5. Press "UP/Down" to select single/multiple players (P1/P2/P3/P4).

Press "PLAY" to begin the game.

"HOME" displays "player", "VISITOR" displays "24" points, pre-set 40 seconds playing time.

Points scored will display on scoreboard "HOME"

Before time is out, once 24/52/68/86 points is scored, playing time increases 10/20/10/20 seconds respectively.

Countdown 5 seconds to next player's turn when one player finishes game.

Player with more points scored wins ( LED will flash on player with higher score).

Game is finished when a player scores 99 points. Press "PLAY" to restart this game

## Around the World

Use tape to mark the shooting lines. Press "PLAY" to enter game 6.

Press "UP/Down" to select single/multiple players (P1/P2/P3/P4).

Press "PLAY" after the number of player is selected.

Scoreboard "HOME" displays Player 1/2/3/4, "VISITOR" displays scored points.

Once score comes to 10 points or time comes to 99 seconds countdown 5 seconds to next player's turn when one player finishes game.

Player who finishes the game first wins (LED will flash on winner). Press "PLAY" to restart this game.

## Left and Right shoot

Press "PLAY" to enter game 7. Press "UP/Down" to select single/multiple players (P1/P2/P3/P4).

Press "PLAY" after the number of player is selected.

Press "UP/Down" to select playing time, 30/45/60 seconds.

Press "PLAY" to begin the game.

Scoreboard "HOME" displays Player, "VISITOR" displays points.

Make a shot in "HOME" frame when LED is flashing on "HOME", 2 points scored display on "HOME".

Make a shot in "VISITOR" frame when LED is flashing on "VISITOR", 2 points scored display on "VISITOR".

Countdown 5 seconds to next player's turn when one player finishes game.

Player with more points scored wins ( LED will flash on player with higher score). Press "PLAY" to restart this game.

## One to One

Press "PLAY" to enter game 8. Press "UP/Down" to select playing time, 30/45/60 seconds.

Press "PLAY" to begin the game.

Shot made in "HOME" frame, 2 points scored for "HOME", all shots count 3 points in last 10 seconds.

Shot made in "VISITOR" frame, 2 points scored for "VISITOR", all shots count 3 points in last 10 seconds.

Player with more points scored wins when time is out.

Press "PLAY" to restart this game.

**This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions :**

**(1) This device may not cause harmful interference.**

**(2) This device must accept any interference received, including interference that may cause undesired operation.**