


# COSORI®

## User Manual

### Pulse Single-Blade Coffee Grinder

Model: CCG-U011-KUS



#### Questions or Concerns?

Mon-Fri, 9:00 am-5:00 pm PST/PDT  
support@cosori.com | (888) 402-1684

 *Thank you for  
your purchase!* 

(We hope you love your new coffee grinder as much as we do.)



*join*

the Cosori Cooks Community on Facebook  
[facebook.com/groups/cosoricooks](https://www.facebook.com/groups/cosoricooks)



*explore*

our recipe gallery  
[www.cosori.com/recipes](http://www.cosori.com/recipes)



*enjoy*

weekly, featured recipes  
made exclusively by our in-house chefs



## CONTACT OUR CHEFS

Our helpful, in-house chefs are ready to assist you with any questions you might have!

**Email:** [recipes@cosori.com](mailto:recipes@cosori.com)

**Toll-Free:** (888) 402-1684

M-F, 9:00 am–5:00 pm PST/PDT

On behalf of all of us at Cosori,

*Happy cooking!*

## Table of Contents

Package Contents	3
Specifications	3
Important Safeguards	4
Getting to Know Your Coffee Grinder	5
Before First Use	6
Grinding Coffee	6
Care & Maintenance	7
Troubleshooting	7
Warranty Information	9
Customer Support	10

## Package Contents

- 1 × Pulse Single-Blade Coffee Grinder
- 1 × Single-Blade Grinding Chamber
- 1 × Grinder Lid
- 1 × Chamber Cover
- 1 × Cleaning Brush
- 1 × User Manual
- 1 × Quick Reference Guide

## Specifications

<b>Power Supply</b>	AC 120V, 60Hz
<b>Rated Power</b>	200W
<b>Capacity</b>	2.5 oz / 70 g
<b>Weight</b>	1.65 lb / 750 g
<b>Dimensions</b>	4 × 4 × 7.6 in / 102 × 102 × 193.5 mm

# READ AND SAVE THESE INSTRUCTIONS

## IMPORTANT SAFEGUARDS

---


Follow basic safety precautions when using your coffee grinder. Read all instructions.

### General Safety

- This coffee grinder was designed to process normal household quantities.
- The coffee grinder should not be used by children. Keep the coffee grinder and its cord out of reach of children.
- **Never** remove the transparent lid before the blades have stopped rotating.
- Unplug the coffee grinder from the outlet when not in use, before putting on or taking off parts, and before cleaning.
- **Do not** use your coffee grinder if it is damaged, not working, or if the cord or plug is damaged. Contact **Customer Support** (see page 10).
- The use of attachments not recommended or sold by Cosori may cause fire, electric shock, or injury.
- **Always** check the grinding chamber for foreign objects before using.
- **Do not** operate the coffee grinder with an empty grinding chamber.
- Your coffee grinder should **only** be used with **120V, 60Hz** electrical systems. **Do not** plug into another type of outlet.
- Not for outdoor or commercial use. Household use **only**.

# GETTING TO KNOW YOUR COFFEE GRINDER

---



- A.** Grinder Lid
- B.** Upper Body
- C.** Clutch
- D.** Base
- E.** On/Off Button
- F.** Stainless Steel Blade
- G.** Single-Blade Grinding Chamber
- H.** Chamber Cover

# BEFORE FIRST USE

---

## Setting Up

1. Remove all plastic and labels from all parts of the coffee grinder.
2. Place the coffee grinder on a hard, flat surface.
3. Plug in the coffee grinder.

## GRINDING COFFEE

---

1. Insert the grinding chamber into the grinder base. Twist to lock into place.
2. Measure out the desired amount of whole coffee beans and place into the grinding chamber.

**Note:** **Do not** fill the grinding chamber past the **MAX** fill line.

3. Place the grinder lid on top of the grinding chamber, aligning the marker on the lid with the unlock symbol on the chamber. Twist clockwise to lock into place.
4. Press and hold the **ON/OFF** button until the coffee grounds reach the desired grind size.

**Note:**

- Grinding coffee beans for a longer duration of time will result in finer grounds. Grinding for a shorter duration of time will result in coarser grounds.
- During grinding, if coffee grounds start collecting on the edge of the grinding chamber, gently shake the coffee grinder so that the coffee grounds fall back inside.
- To prevent overheating, **do not** operate the coffee grinder continuously for more than 1 minute. Let the coffee grinder cool for 3 minutes before using it again.

Please refer to the **Coffee Grinding Chart** below for guidance on choosing a grind size for your preferred brewing method.

## Coffee Grinding Chart

Duration	Grind Size	Brewing Methods
8–10 seconds	Coarse	French Press, Cold Brew
10–12 seconds	Medium	Pour Over, Drip
12–15 seconds	Fine	Espresso, Moka Pot

# CARE & MAINTENANCE

---

## Cleaning the Coffee Grinder

The coffee grinder should be thoroughly cleaned after each use and before storing.

1. Unplug the coffee grinder.
2. Wash the grinder lid and chamber cover by hand or in the dishwasher.

**Note:** *If using a dishwasher, place the grinder lid and chamber cover on the top rack.*

3. Carefully clean the blade area of the grinding chamber with the included cleaning brush.

4. Wipe the outside of the coffee grinder with a damp cloth.
5. Dry all parts with a cloth. Make sure all parts are completely dry before reassembling or storing.

## Storage

Follow the cleaning instructions above and allow all parts to dry completely before storing. Store in a cool, dry location with the grinding chamber covered with the chamber cover.

# TROUBLESHOOTING

---

Problem	Possible Solution
The coffee grinder will not turn on.	Make sure the plug is connected to a power outlet.
	Make sure the grinder lid is locked into place.
The coffee grinder has stopped working after using for more than 1 minute.	Unplug the coffee grinder and allow it to cool for 30 minutes before using it again.
Coffee grounds are getting stuck and not circulating during grinding.	Stop grinding and gently shake the coffee grinder up and down to redistribute the grounds.
Coffee grounds are being ground too finely.	Hold the <b>ON/OFF</b> button down for a shorter period of time for a coarser grind size.
The grind sizes are inconsistent.	Hold the <b>ON/OFF</b> button consistently without letting go for consistent grind sizes.

If your problem is not listed, please contact **Customer Support** (see page 10).

# FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

---

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- [1] This device may not cause harmful interference, and
- [2] This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.



# WARRANTY INFORMATION

<b>Product</b>	<i>Pulse Single-Blade Coffee Grinder</i>
<b>Model</b>	<i>CCG-U011-KUS</i>
For your own reference, we strongly recommend that you record your order ID and date of purchase.	
<b>Order ID</b>	
<b>Date of Purchase</b>	

## TERMS & POLICY

Arovast Corporation ("Arovast") warrants this product to the original purchaser to be free from defects in material and workmanship, under normal use and conditions, for a period of 1 year from the date of original purchase.

Arovast agrees, at our option during the warranty period, to repair any defect in material or workmanship or furnish an equal product in exchange without charge, subject to verification of the defect or malfunction and proof of the date of purchase.

There is no other express warranty. This warranty does not apply:

- If the product has been modified from its original condition;
- If the product has not been used in accordance with directions and instructions in the user manual;
- To damages or defects caused by accident, abuse, misuse or improper or inadequate maintenance;
- To damages or defects caused by service or repair of the product performed by an unauthorized service provider or by anyone other than Arovast;
- To damages or defects occurring during commercial use, rental use, or any use for which the product is not intended;
- To damages or defects exceeding the cost of the product.

Arovast will not be liable for indirect, incidental, or consequential damages in connection with the use of the product covered by this warranty.

This warranty extends only to the original consumer purchaser of the product and is not transferable to any subsequent owner of the product regardless of whether the product is transferred during the specified term of the warranty.

This warranty does not extend to products purchased from unauthorized sellers. Arovast's warranty extends only to products purchased from authorized sellers that are subject to Arovast's quality controls and have agreed to follow its quality controls.

All implied warranties are limited to the period of this limited warranty.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

If you discover that your product is defective within the specified warranty period, please contact Customer Support via [support@cosori.com](mailto:support@cosori.com). DO NOT dispose of your product before contacting us. Once our Customer Support Team has approved your request, please return the product with a copy of the invoice and order ID.

### Extend Your Warranty by 1 Year

Register your product within 14 days of purchase at [www.cosori.com/warranty](http://www.cosori.com/warranty) to extend your 1-year warranty by an additional year.

This warranty is made by:

Arovast Corporation  
1202 N. Miller St., Suite A  
Anaheim, CA 92806

# CUSTOMER SUPPORT

---

If you have any questions or concerns about your new product, please contact our helpful Customer Support Team.

**Arovast Corporation**

1202 N. Miller St., Suite A  
Anaheim, CA 92806

**Support Hours**

Mon–Fri, 9:00 am–5:00 pm  
PST/PDT

**Email:** [support@cosori.com](mailto:support@cosori.com)

**Toll-Free:** (888) 402-1684

\*Please have your order invoice and order ID ready before contacting Customer Support.

## SHOW US WHAT YOU'RE MAKING

---

We hope this manual has been helpful. We can't wait to see your beautiful results, and we think you'll want to share glam shots! Our community awaits your uploads—just pick your platform of choice below. Snap, tag, and hashtag away, Cosori chef!

Considering what to cook? Many recipe ideas are available, both from us and the Cosori community.

**#iCookCosori**



**@cosoricooks**



**Cosori Appliances**

## MORE COSORI PRODUCTS

---

If you're happy with this coffee grinder, the line doesn't stop here. Check out **[www.cosori.com](http://www.cosori.com)** for a line of all our beautiful and thoughtfully designed cookware. They might be right at home in your kitchen, too!

# COSORI®

**Questions or Concerns?**

support@cosori.com | (888) 402-1684  
Mon-Fri, 9:00 am-5:00 pm PST/PDT