

Be sure to write your model number and serial number here for future reference. You can find these numbers printed on the bottom of the table.

MODEL NO.: T8725W/F DATE CODE : CPSIA#2-T8725W/F-____ PURCHASE DATE :

-SY

OWNER'S MANUAL

- 1. Read this manual carefully before starting assembly. Read each step completely before beginning each step.
- 2. Some smaller parts may be shipped inside larger parts. Check inside all parts and cartons before assembling or ordering parts.
- **3.** If hardware is tightened too soon, mounting holes may not align and parts may not easily fit together. Leave bolts slightly loose until you are instructed to tighten them.
- 4. To make assembly as easy as possible, place all parts of the table tennis in a cleared area and remove the packaging material. Organize all parts as per parts identifier in the assembly manual. Do not dispose of the packing material until assembly is completed.
- 5. Avoid scratching table tennis top and metal tube parts during the assembly process.
- 6. Assemble product on clean, level and flat surface.
- 7. Take time to correctly orientate parts exactly as per each assembly diagram.
- 8. Save this instruction in the event that the manufacturer has to be contacted for replacement parts.



READ ASSEMBLY, OPERATING AND SAFETY INSTRUCTIONS CAUTION: CAREFULLY! AT LEAST TWO ADULTS ARE NEEDED TO PUT THIS TABLE TOGETHER!

Thank you for buying our product. We try hard to ensure that our products are of high quality and free of problems, such as Manufacturing defects or missing parts. However, if you have any problems with your new product, please DO NOT RETURN IT TO THE STORE

Please Do Not Return This Product To The Store!

Contact Escalade® Sports customer service department at:

Phone: 1-866-873-3528 Toll-Free! 1-866-873-3533 Toll-Free! Fax: E-mail: tabletennis@escaladesports.com

Mailing Address (correspondence only): Escalade Sports PO Box 889, Evansville, IN 47706 Physical Location: **Escalade Sports** 817 Maxwell Ave. Evansville, IN 47711

Please provide model number and/or part number of the product and/or part when you call or write. These numbers can be found on the product, packaging, and/or in this Owner's Manual.

Please visit our website at: www.escaladesports.com ON-LINE TROUBLE SHOOTING **TECHNICAL ASSISTANCE ON-LINE PARTS REQUESTS** FREQUENTLY ASKED QUESTIONS ADDITIONAL ESCALADE® SPORTS PRODUCT INFORMANTION



Escalade® Sport products may be manufactured and/or licensed under the following patents. 6120397 , 5816957 , 5769744 , 5119741 , 4911085 , 4717157 , D460140 , D420563 Additional patents may be pending. One or more of the listed patents and/or pending patents may cover specific product.

CARE AND MAINTENANCE

You have purchased a quality product that will give you years of enjoyment. By following these simple maintenance steps, you will add to the life of your new table.

THE TABLE TOP

The top (playing surface) of your table is made of Particle Board. Like all products made of wood, it can be affected by atmospheric changes in both temperature and humidity. This may cause a slight sag or distortion as the top expands or contracts. This is normal and should not cause concern as it does not detract from the play or utility value of the table. After assembly of the table, you can minimize the effects of temperature and humidity changes by storing the table in a dry area when table is not in use.

STORAGE OF YOUR TABLE

This table must be stored indoors to prevent damage to the playing surface. Dampness and extreme temperature changes can cause the wood to warp, swell, crack or blister. When your table is not in use, it should be stored in a dry area. Due to the nature of particle board, table top may bow. Damp and humid conditions will amplify this. This is normal and will not affect playability of table.

CLEANING YOUR TABLE

To clean your table use a soft, damp (NOT WET) cloth only. To prevent damage to your table's playing surface, DO NOT USE ANY CHEMICALS, ABRASIVE OR CLEANING PRODUCTS on your table's playing surface.

MAINTENANCE OF YOUR TABLE

Be sure to oil all moving parts of your table including the pivot points. This will insure the safety and ease of use of your table.

This table must be kept indoors to prevent damage to the playing surface. Dampness and extreme temperature changes which occur on patios or similar areas can cause wood to warp, swell, crack or blister.

UNLEVEL FLOORS

If table does not seem level, it is probably due to uneven or unlevel floors. Set the table in its PLAYING POSITION and move table several inches in different directions to find the best location for the table. If the floor is extremely unlevel, table may not play or operate properly. If table is high in the center, shim up under the outer legs.


TRANSPORTING THE FOLDED TABLE TOPS

It is recommended to keep the carton for folded table storage and or transport.

Also, note when folded, the table has casters on the bottom side to make movement easier.


When transporting the folded half tops, be careful not to damage the lower corners or scratch the playing surfaces.

HARDWARE IDENTIFIER (To Scale)



H1 - 8 mm x 40 mm Tensioning Knob Bolt - Short (4 pcs) H2 - 8 mm x 55 mm Knob Bolt - Long (8 pcs)

PARTS IDENTIFIER (Not to Scale)




IMPORTANT NOTE: Place table half top with playing surface face down on a CLEAN flat surface for ease of correct assembly and to prevent any scratches or blemishes to the playing surface.

PARTS REQUIRED

1 pc - **P1** Table Tennis Table Top and Frame Assembly

STEP 1:

Lay one piece **P1** Table Tennis Table Top and Frame Assembly flat with playing surface facing down as shown in **FIGURE 1**.




PARTS REQUIRED

4 pcs - **P5** Upper Leg Connector 8 pcs - **H2** Knob Bolt - Long

STEP 3:

Install **P5** Upper Leg Connector with **P3** Lower "A"Leg Connector and **P4** Lower "B"Leg Connector using **H2** Knob Bolt - Long as shown in **FIGURE 3** & **DETAIL B,C,D,E**. Tighten this hardware. **DO NOT OVERTIGHTEN AND CRUSH TUBES.**

Repeat procedures for other table top.



WARNING

THIS STEP REQUIRES TWO CAPABLE ADULTS. VERY CAREFULLY TURN THE TABLE OVER AND SET IT ON ITS LEGS. BE CAREFUL THE TABLE IS HEAVY DROPPING THE TABLE CAN CAUSE SERIOUS INJURIES OR PROPERTY DAMAGES.

PARTS REQUIRED


2 pcs - **P6** Net Post 1 pc - **P7** Net 4 pcs - **H1** Tensioning Knob Bolt – Short

STEP 4:

Attach one **P6** Net Post to the middle edge of where the table halves meet. Repeat this with other **P6** Net Post on opposite side.

Then, slide P7 Net into corresponding P6 Net Post and repeat for the other side as shown in DETAIL F.

Install **H1** Tensioning Knob Bolt - Short, in one end of each **P5** Upper Leg Connector as shown in **DETAIL G.** Snug Tighten these 4 pcs of **H1** Tensioning Knob Bolt - Short. **Do not overtighten.**




CAUTION: TABLE! SERIOUS OR FATAL INJURY MAY RESULT! THIS IS NOT A TOY! TABLE IS TO BE OPENED OR CLOSED BY ADULTS ONLY! FAILURE TO COMPLY WITH OPENING AND CLOSING INSTRUCTIONS COULD RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE.

STORAGE OF THE TABLE:


STEP 1:

Remove the **P7** Net and **P6** Net Posts as shown in **FIGURE 5**.



STEP 2:

Remove **H1** Tensioning Knob Bolt - Short, and **H2** Knob Bolts - Long, as shown in **FIGURE 6.**



STEP 3:


Fold each Leg and half table as shown in **FIGURE 7**.


FIGURE 7



STEP 4:

Lock the table using **SAFETY LOCK** as shown in **FIGURE 8**.





T8725 TABLE TENNIS TABLE SPARE PARTS

Key#	ŧ Part No.	Description	Qty
H1	T8725SY-H1	8 mm x 40 mm Tensioning Knob Bolt - Short	4
H2	T8725SY-H2	8 mm x 55 mm Knob Bolt - Long	8
P1	T8725SY-P1	Table Tennis Table Top and Frame Assembly	2
P2	T8725SY-P2	Leg With Leg Caps (Pre-installed)	4
Р3	T8725SY-P3	Lower "A"Leg Connector (Pre-installed)	8
P4	T8725SY-P4	Lower "B"Leg Connector (Pre-installed)	8
P5	T8725SY-P5	Upper Leg Connector	4
P6	T8725SY-P6	Net Post	2
P7	T8725SY-P7	Net	1
DETA	IL A		
C2	T8725SY-C2	8 mm x 75 mm Allen Head Bolt	8
C5	t8725SY-C5	8 mm x 22 mm Flat Washer	16
C6	T8725SY-C6	8 mm Nylon Lock Nut	8
C7	T8725SY-C7	8 mm x 18 mm Plastic Bushing	8
DETA			
C3	T8725SY-C3	8 mm x 50 mm Allen Head Bolt	8
C5	T8725SY-C5	8 mm x 22 mm Flat Washer	8
C6	T8725SY-C6	8mm Nylon Lock Nut	8
C8	T8725SY-C8	8 mm x 16 mm Plastic Step Bushing	16
DETA			
C4	T8725SY-C4	8 mm x 35 mm Allen Head Bolt	8
C5	T8725SY-C5	8 mm x 22 mm Flat Washer	16
C6	T8725SY-C6	8mm Nylon Lock Nut	8
C10	T8725SY-C10 T8725SY-C14	3.5 mm x 14 mm Round Head Screw Plasitc Bracket	32 8
C14	10/2001-014		0
DETA			1.4
C10 C11		3.5 mm x 14 mm Round Head Screw	16 8
	T8725SY-C11	Plasitc Leg Cap	0
DETA			
C9	T8725SY-C9	3.5 mm x 12 mm Round Head Screw	8
C16	T8725SY-C16	Safety Lock	2
DETA	ALL F		
H1	T8725SY-H1	8 mm x 40 mm Tensioning Knob Bolt - Short	4
H2	T8725SY-H2	8 mm x 55 mm Knob Bolt - Long	8
C8	t8725SY-C8	8 mm x 16 mm Plastic Step Bushing	8
			-

T8485 TABLE TENNIS TABLE SPARE PARTS

Key#	Part No.	Description	Qty		
DETAIL G					
C1	T8725SY-C1	3.5 mm x 18 mm Flat Head Screw	48		
C10	T8725SY-C10	3.5 mm x 14 mm Round Head Screw	16		
C12	T8725SY-C12	Hinge	6		
C13	T8725SY-C13	Wheel	4		
DETAI	LH				
C17	T8725SY-C <mark>17</mark>	6 mm x 55 mm Allen Head Bolt	8		
C18	t8725SY-C <mark>18</mark>	6 mm x 18 mm Plastic Flat Washer	16		
C19	T8725SY-C6	6 mm Nylon Lock Nut	8		
C10	T8725SY-C10	3.5 mm x 14 mm Round Head Screw	32		
C15	T8725SY-C15	Metal Bracket	8		

90 DAY LIMITED WARRANTY

This consumer warranty extends to the original consumer purchase of any ESCALADE® SPORTS Product (hereinafter referred as the "Product").

WARRANTY DURATION: This Product is warranted to the original consumer purchase of a period of ninety (90) days from the original purchase.

WARRANTY COVERAGE: ESCALADE® SPORTS warrants to the original Consumer Purchaser that any Product of its manufacture is free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

WARRANTY PERFORMANCE: During the above ninety (90) day warranty period, ESCALADE® SPORTS shall repair or replace with a comparable model, and Product, or component thereof, which may prove defective under normal use and proper care, and which our examination shall disclose to our satisfaction to be thus defective, please contact our Warranty Dept.

1-866-873-3528 / Warranty Dept.

Or Write us at: Escalade[®] Sports, Inc. - P.O. Box 889, Evansville, IN 47706 - Attn: Warranty Dept.

> Or E-mail us at: customerservice@escaladesports.com

Other than shipping requirements no charge will be made for such repair or replacement of in-warranty Products. ESCALADE® SPORTS strongly recommends that the Product is insured for value prior to mailing.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE NINETY (90) DAY WARRANTY PERIOD. ESCALADE® SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEDIES: This warranty give you specific legal rights and you may also have other rights which may vary from state to state.