

SpotClean

5207 9749 7786

No Spray

- 1) Make sure there is water in the solution tank. Verify which tank the water and solution is in.
- 2) Clean the insert at the bottom of the Clean water/solution tank.
- 3) Make sure solution tank is securely seated into place. The SpotClean Clean water/solution tank should be put back into the machine by lining up the tank bottom with the indentations on the machine (See picture below). Press down firmly on the tank to make sure it is secure in position and there are no gaps between the tank and base of the machine.



- 4) With tool removed, check to see if wand sprays by depressing the trigger.



- a) If the wand **DOES NOT** spray, clean the spray nozzle using an unfolded paperclip. (See picture below)



- a. Make sure the Clean Water/Solution tank has solution/water in it.
 - b. Check to see if water comes through the insert on the bottom of the Clean water/solution tank by pushing up on the small round valve.
 - i. If **NO** water comes through the valve, the tank may need to be replaced. ** *(The valve is not a replaceable part, an entire tank would need to be ordered)*
 - ii. If **YES** water comes through the valve, the machine may have lost its prime. Gently lift the Clean Water/Solution tank while depressing the spray trigger **OR** gently squeeze the clean tank while depressing the spray trigger
- b) If the wand **DOES** spray without the tool attached, clean the tool's spray tip with a brush, and also by using a paperclip to clean out any clog in the spray tip. Also, check the tool for any cracks. Replace if necessary.
- i. **Did this work? If not.....**
 1. Suction up several tanks full of warm clean water into the collection tank. This will clear clogs from the solution line inside the flex hose. Once this has been done, try to spray again.
 2. **If still no spray**, please take the machine to a BISSELL Authorized Service Center to have a Quality Technician inspect the unit.