


## OWNER'S MANUAL - ASSEMBLY INSTRUCTIONS CRICKET - BABY WALKER BALANCE BIKE

### ⚠ WARNING


- Read and understand this entire manual BEFORE allowing child to use this product.
- Keep this manual for your records, it contains important information.
- For ages 12-24 months, max. rider weight 44/20kgs
- Adult assembly required.

### TOOLS




4mm hex wrench  
(included)


### PARTS




**x1**  
Main Body




**x1**  
Front Wheels



**x1**  
Handlebars




**x1**  
Bolt



**x1**  
Nut


- 1** Using the included 4mm hex wrench, remove the Bolt from the Front Wheels assembly **Fig 1**. Keep this bolt handy, you will reinstall it in a moment.

On the opposite side of the bolt there is a nut which is factory installed in The Front Wheels assembly – it should stay secured in the Front Wheels assembly. However, keep the Front Wheels assembly upright or gently on its side, do not bang, drop, or attempt to remove the nut.




**Fig 1.**

- 2** Working on a flat, firm surface, and with the Front Wheels facing forward, insert the Front Wheels assembly into the bottom of the Main Body. **Fig 2**




**Fig 2.**

- 3** Insert the Handlebars into the top of the Main Body. Make sure the Front Wheels and Handlebar are fully inserted into the Main Body and fully mated and engaged with one another **Fig 3** and are flush/no gaps with the front Main Body tube **Fig 4**.




**Fig 3.**



**Fig 4.**

- 4** Reinstall the bolt through the hole from which you removed it earlier **Fig 4**. Tighten securely Push the Handlebar into the Main Tube and Front Wheels, again making sure both parts are fully engaged and flush to the Main Body front tube. The bolt will be facing rearwards/toward the rider. Completed it will look like **Fig 5**.



**Fig 5.**

## **⚠ WARNING**

- Do not ride at night.
- Adult supervision is required.
- Do not use near or in traffic.
- Never leave child unattended.
- Inspect product before and after each use. If there is any damage, stop using it immediately. Repair or replace by a qualified technician.
- Replace all worn and broken parts immediately.
- Check your environment – make sure the surroundings are safe for use.
- Make sure you dispose of all plastic packaging responsibly and keep out of children's reach.
- Children must always hold on to the handlebars when riding.
- Ride on smooth surfaces away from vehicles.
- Avoid sharp bumps, drainage grates, and sudden surface changes which would cause Cricket to stop.
- Read and understand the enclosed owner's manual and assembly instructions, and all other literature and warnings before riding.
- Always wear protective safety equipment, such as helmet, knee pads, elbow pads, and shoes.
- Do not use on streets and surfaces with water, sand, gravel, dirt, leaves, and other debris. Wet weather impairs traction stopping, and visibility.
- Never use near swimming pools, hills, steps, or over rough or uneven surfaces.
- Rider weight does not necessarily mean a child's size is appropriate to fit or maintain control on this mini balance bike.
- A parent's decision to allow his or her child to ride this product should be based on the child's skill, maturity, and ability.
- Watch out for obstacles that could catch your wheel or force you to turn suddenly or lose control.
- Never use in roadways, near motor vehicles, on or near hills or steps, swimming pools or other bodies of water.
- This bike is toy. Therefore, it should not be ridden on streets, roads, bike paths, or dangerous places. Use in a safe place.
- Use only a moist cloth to clean. Do not use harsh chemicals or solvents.