



User Manual

SAFETY INTRODUCTION

- If the device has been exposed to temperature changes due to environmental changes, do not switch it on
 immediately. The arising condensation could damage the device. Leave the device switched off until it has
 reached room temperature.
- It is essential that the device is earthed. A qualified person must carry out the electric connection.
- Make sure that the available voltage is not higher than stated at the end of this manual.
- Make sure the power cord is never crimped or damaged. If it is damaged, ask your dealer or authorized agent to replace the power cord.
- Always disconnect from the mains, when the device is not in use or before cleaning it. Only handle the power cord by plug. Never pull out the plug by tugging the power cord.
- DISCONNECT DEVICE: Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

CAUTION

1. Be very careful during installation. Since you will be working with a dangerous voltage you can suffer a life-threatening electric shock when touching live wired.

2. Please be aware that damages caused by manual modifications to the device are not subject to warranty. Keep away from children and non-professionals.

3. The unit doesn't include any spare parts for repair, please check if all the parts are well installed and screws are fitted tightly before operating. Do not use the unit when the cover is open.

GENERAL GUIDELINES

- This device is only allowed to be operated with an alternating current of 220-240Vac/50-60Hz and was designed for indoor use only.
- Do not shake the device. Avoid brute force when installing or operating it.
- · Please make sure that the device is not exposed to extreme heat, moisture or dust.
- Operate the device only after having familiarized yourself with its functions. Do not permit operation by person not qualified for operating the device. Most damages are the result of unprofessional operation.
- · Please use the original packaging if the device is to be transported.
- For safety reasons, please be aware that all modifications on the device are forbidden. Furthermore, any other
 operation may lead to short-circuit, burns, electric shock, crash, etc. If this device will be operated in any way
 different to the one described in this manual, the product may suffer damages and the guarantee becomes void.
- This device is not water-proof or splash-proof

INSTALLATION

Orientation

This fixture may be mounted in flat position, provided there is adequate room for ventilation

It is important never to obstruct the fan or vents pathway.

When selecting installation location, take into consideration routine maintenance.

Safety cables must always be used.

Never mount in places where the fixture will be exposed to rain, high humidity, extreme temperature changes or restricted ventilation.

If the external flexible cable or cord of this device is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

Make sure the installation position is stable before you place the device. We will not take any responsibility for damages caused by a badly installed unit.

Power Supply Connection

The exclusive plug should be used between the connection of unit and power. Please ensure that the rated voltage and frequency are accordance with the power supply. The required input voltage and frequency are: 220-240Vac – 50-60Hz

Note: the ground wire (yellow/green double-color wire) must be safely connected; the electrical installation must be in accordance with the related standards

OPERATION

- Switch the device on in using the power switch located on the rear panel of the bubble machine.
- You will notice that internal bubble drum and fan are activated. Bubbles are now produced.
- Use wireless remote control to activate the production of bubble

Cleaning and Using Frequency of Product

Please make sure that the device is power off before dismantling or maintaining, it's very important to keep the unit clean. Frequent cleaning will prolong the life time. It's not allowed to use alcohol or chemical solvent.

When the device doesn't work, please check if the fuse is burnt out or not. If it is, the same fuse should be replaced, find out the faulty and restart the light. But please note the repair must be handled by professional.

TECHNICAL SPECIFICATIONS

Voltage:	
Power	
Warming up time	7mn
Spray distance	9m
Coverage	
Fog liquid bottle capacity	2.5L
Dimensions:	500 x 480 x 410mm
N.W	
Electric products must not be put into house	old waste. Please bring them to a r

X

Electric products must not be put into household waste. Please bring them to a recycling centre. Ask your local authorities or your dealer about the way to proceed.

