





X Mount Bar Pro

Assembly instructions HL6800H




Parts

- A** x1 — Phone Mount
- B** x1 — Arm with Handlebar Clamp
- C** x2 — Rubber Shim
- D** x1 — Handlebar Stem Support
- E** x1 — Clamp Screw
- F** x1 — Mount Screw
- G** x1 — Garmin® Mount
- H** x1 — Wahoo® Mount

Tools Required

Allen Key (4mm) and (2.5 mm)

(Included)



WARNING


Using phone device while riding can cause accidents resulting in serious injury.

Important: Nuts and bolts can loosen over time, resulting in serious danger should the item fall off while in motion. Check frequently to ensure all bolts are properly tightened. Ensure the device fits snugly in the holder before riding. Not for off-road use.


- 1 Determine which handlebar shim is best suited for your needs, insert into handlebar stem support (FIGURE 1). Once attached clip on to handlebar.

**IMPORTANT NOTE**

Be sure stem support is positioned underneath stem.




- 2 Slide hinge mount arm over stem support (FIGURE 1). Clamp to close, once in position, tighten clamp screw with Allen key (4mm).

FIGURE 1**IMPORTANT NOTE**


Do not attach clamp to any tapered section of your handlebar.

GARMIN® OR WAHOO® MOUNTING OPTIONS

- 1 Use Allen key (2.5mm) to remove mount screw.



- 2 Choose Garmin® or Wahoo® mount, position on to arm. Tighten mount screw with Allen key (2.5mm).



Delta Cycle Corporation
36 York Avenue, Randolph, MA 02368 USA
800-474-6615 / www.designbydelta.com

Service: Please do not return to store;
for immediate response email
service@designbydelta.com

