Dell EMC PowerEdge C6400

Technical Specifications



Notes, cautions, and warnings
i NOTE: A NOTE indicates important information that helps you make better use of your product.
CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.
MARNING: A WARNING indicates a potential for property damage, personal injury, or death.
© 2017 - 2018 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other
trademarks may be trademarks of their respective owners.

2019 - 04

Contents

1 Dell EMC PowerEdge C6400 overview	4
2 Technical specifications	5
Dimensions of the Dell EMC PowerEdge C6400 enclosure	
Chassis weight	
Supported operating systems	
PSU specifications	
Chassis management board specifications	
Drives and storage specifications	
Midplane specifications	
Environmental specifications	
Standard operating temperature specifications	
Expanded operating temperature specifications	
Particulate and gaseous contamination specifications	
Maximum vibration specifications	21
Maximum shock specifications	22
Maximum altitude specifications	22
Fresh Air Operation	22
3 Documentation resources	23
4 Getting help4	25
Contacting Dell EMC	
Documentation feedback	25
Accessing system information by using QRL	25
Quick Resource Locator for C6400 and C6420 systems	26
Receiving automated support with SupportAssist	26
Recycling or End-of-Life service information	26

Dell EMC PowerEdge C6400 overview

The PowerEdge C6400 is an ultra-dense 2U enclosure that can support up to four independent two-socket (2S) sleds. The PowerEdge C6400 enclosure supports the following drive configurations:

- up to 24 x 2.5-inch SAS or SATA drives
- up to 8 x 2.5-inch NVMe drives, with 16 x 2.5-inch SAS or SATA drives
- up to 12 x 3.5-inch SAS or SATA drives
- · diskless no backplane

Technical specifications

The technical and environmental specifications of your system are outlined in this section.

Topics:

- · Dimensions of the Dell EMC PowerEdge C6400 enclosure
- · Chassis weight
- · Supported operating systems
- PSU specifications
- · Chassis management board specifications
- · Drives and storage specifications
- Midplane specifications
- · Environmental specifications

Dimensions of the Dell EMC PowerEdge C6400 enclosure




Figure 1. Dimensions of PowerEdge C6400 enclosure

Table 1. Dimensions of the PowerEdge C6400 enclosure

Xa	Xb	Y	Za	Zb	Zc
482.6 mm (19 inches)	448 mm (17.63 inches)	86.8 mm (3.41 inches)	26.8 mm (1.05 inches)	763.2 mm (30.28 inches)	797.3 mm (31.38 inches)

Chassis weight

Table 2. Chassis weight of the Dell EMC PowerEdge C6400 enclosure with PowerEdge C6420 sleds

System	Maximum weight (with all sleds and drives)
12 x 3.5-inch hard drive systems	43.62 Kg (96.16 lb)
24 x 2.5-inch hard drive systems	41.46 Kg (91.40 lb)
No backplane systems	34.56 Kg (76.19 lb)

Supported operating systems

The Dell EMC PowerEdge C6400 supports the following operating systems:

- · Canonical Ubuntu LTS
- · Citrix XenServer
- · Microsoft Windows Server with Hyper-V
- · Red Hat Enterprise Linux
- SUSE Linux Enterprise Server
- VMware ESXi

(i) NOTE: For more information about the specific versions and additions, see https://www.dell.com/support/home/drivers/supportedos/poweredge-c6400

PSU specifications

The Dell EMC PowerEdge C6400 enclosure supports two AC power supply units (PSUs).

Table 3. PSU specifications

PSU wattage	Class	Heat dissipation (maximum)	Frequency	Voltage	Maximum input current
2400 W AC	Platinum	9000 BTU/hr	50/60 Hz	100–240 V AC, autoranging	14 A-16 A
2000 W AC	Platinum	7500 BTU/hr	50/60 Hz	100–240 V AC, autoranging	11.5 A
1600 W AC	Platinum	6000 BTU/hr	50/60 Hz	100–240 V AC, autoranging	10 A

- i NOTE: Heat dissipation is calculated using the PSU wattage rating.
- 1 NOTE: This system is also designed to connect to the IT power systems with a phase to phase voltage not exceeding 240 V.
- 1 NOTE: If a system with 2400 W AC PSU operates at low line 100–120 V AC, then the power rating per PSU is derated to 1400 W.
- 1 NOTE: If a system with 2000 W AC PSU operates at low line 100–120 V AC, then the power rating per PSU is derated to 1000 W.
- 1 NOTE: If system with 1600 W AC PSU operates at low line 100–120 V AC, then the power rating per PSU is derated to 800 W.

Chassis management board specifications




Figure 2. Chassis management board specifications

- 1 Fan cage 1 connector for fans 1 and 2
- 3 Chassis management board signal cable to backplane
- 5 Chassis management board signal cable to PIB
- 7 MCU connector
- 9 Firmware jumpers
- 11 Fan cage 2 connector for fans 3 and 4

- 2 Left midplane signal cable
- 4 Chassis management board power connector from PIB
- 6 FPGA connector
- 8 COM connector
- 10 Right midplane signal cable

Drives and storage specifications

The Dell EMC PowerEdge C6400 enclosure supports SAS and SATA hard drives and Solid State Drives (SSDs).

Table 4. Supported drive options for the Dell EMC PowerEdge C6400 enclosure

Maximum number of drives in the enclosureMaximum number of drives assigned per sled12 x 3.5-inch drive systemsThree SAS or SATA hard drives and SSDs per sled24 x 2.5-inch drive systemsSix SAS or SATA hard drives and SSDs per sled24 x 2.5-inch drive systems with NVMeThe NVMe backplane supports either of these configurations:• Two NVMe drives and four SAS or SATA hard drives and SSDs per sled• Six SAS or SATA hard drives and SSDs per sled

M.2 SATA drive (optional)

The supported capacity of the M.2 SATA card is up to 240 GB

(i) NOTE: The M.2 SATA card can be installed on the x16 riser slot (slot 5).

Micro-SD card (optional) for boot (up to 64 GB)

One on each PCle riser of each sled

Table 5. Supported RAID options with M.2 SATA drives

Options	Single M.2 SATA drive without RAID	Dual M.2 SATA drives with hardware RAID
Hardware RAID	No	Yes
RAID Mode	N/A	RAID 1
Number of drives supported	1	2
Supported CPUs	CPU 1	CPU 1 and CPU 2

Midplane specifications




Figure 3. Midplane specifications

- 1 Midplane signal connector 2
- 3 Chassis management board cable connector
- 5 Midplane power cable ground connector

- 2 Thermal sensor cable connector
- 4 Midplane +12 V power cable connector

Environmental specifications

The sections below contains information about the environmental specifications of the system.

NOTE: For additional information about environmental certifications, please refer to the Product Environmental Datasheet located with the Manuals & Documents on Dell.com/poweredgemanuals

Standard operating temperature specifications

i NOTE:

- 1 Not available: Indicates that the configuration is not offered by Dell EMC.
- 2 Not supported: Indicates that the configuration is not thermally supported.
- (i) NOTE: All components including the DIMMs, communication cards, M.2 SATA, and PERC cards can be supported with sufficient thermal margin if the ambient temperature is equal to or below to the maximum continuous operating temperature listed in these tables except for the Mellanox DP LP card and Intel Rush Creek card.

Table 6. Standard operating temperature specifications

Standard operating temperature	Specifications
Temperature ranges (for altitude less than 950 m or 3117 ft)	10°C-35°C (50°F-95°F) with no direct sunlight on the equipment.

(i) NOTE: Some configurations require a lower ambient temperature. For more information, see the following tables.

Table 7. Maximum continuous operating temperature for nonfabric dual processor configuration

TDD	D	III at abul.	Max memor	3.5-inch	chassis	i	2.5-ind	ch chas	sis		Drive Drive I 21 21 2 21 21 2 21 21 2 21 21 2 21 21 2		No-BP Chassis
TDP Watts	Processo r model	Heat sink model	y/ proces sor	12x Drives	8x Drives	4x Drive s	24x Drive s	20x Driv es	16x Drives	12x Drive s	Drive	4x Drive s	N/A
	8280	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8					20	21	21	21	21	30
	8280L	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8					20	21	21	21	21	30
205 W	8280M	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8	Not Suppor ted (2°C)	Not Suppo rted (10°C	Not Supp orted (11°C	Not Supp orte d(19° C)	20	21	21	21	21	30
	8270	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8					20	21	21	21	21	30
	8268	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8					20	21	21	21	21	30
200 W	6254	CPU1: FMM2M	CPU1: 6	Not Suppor	Not Suppo	Not Supp	20	21	22	22	22	22	30

TDP			Max memor	3.5-inch	n chassis	i	2.5-inch chassis						No-BP Chassis	
TDP Watts	Processo r model	Heat sink model	y/ proces sor	12x Drives	8x Drives	4x Drive s	24x Drive s	20x Driv es	16x Drives	12x Drive s	8x Drive s	4x Drive s	N/A	
		CPU2: V2DRD	CPU2:	ted(6° C)	rted(1 4°C)	orted(15°C)								
	8276	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8				30	30	30	30	30	35	35	
	8276L	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8				30	30	30	30	30	35	35	
	8276M	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8				30	30	30	30	30	35	35	
165 W	8260	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	Not Suppor ted(11° C)	Not Suppo rted(1 8°C)	Suppo rted(1	Not Supp orted(19°C)	30	30	30	30	30	35	35
	8260L	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8				30	30	30	30	30	35	35	
	8260M	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8				30	30	30	30	30	35	35	
	8260C	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8				30	30	30	30	30	35	35	
	6252	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8		21	23	30	30	30	30	30	35	35	
150 W	6248	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	Not Suppor ted(14 °C)	21	23	30	30	30	30	30	35	35	
	6240	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8		21	23	30	30	30	30	30	35	35	

			Max memor	3.5-incl	n chassis	}	2.5-inch chassis						No-BP Chassis
TDP Watts	Processo r model	Heat sink model	y/ proces sor	12x Drives	8x Drives	4x Drive s	24x Drive s	20x Driv es	16x Drives	12x Drive s	8x Drive s	4x Drive s	N/A
	6242	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8		21	23	30	30	30	30	30	35	35
	6244	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8		21	23	30	30	30	30	30	35	35
	6240C	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8		21	23	30	30	30	30	30	35	35
	6230	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	25	30	30	30	30	35	35	35	35	35
	5220	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	25	30	30	30	30	35	35	35	35	35
	5218	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	25	30	30	30	30	35	35	35	35	35
125 W	5218B	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	25	30	30	30	30	35	35	35	35	35
	8253	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	25	30	30	30	30	35	35	35	35	35
	6238T	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	25	30	30	30	30	35	35	35	35	35
	6230N	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	25	30	30	30	30	35	35	35	35	35
115 W	5217	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8	25	30	30	30	30	35	35	35	35	35

			Max memor	3.5-incl	h chassis	3	2.5-in	ch chas	ssis				No-BP Chassis
TDP Watts	Processo r model	Heat sink model	y/ proces sor	12x Drives	8x Drives	4x Drive s	24x Drive s	20x Driv es	16x Drives	12x Drive s	8x Drive s	4x Drive s	N/A
	5218T	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8	30	35	35	35	35	35	35	35	35	35
	5218N	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8	30	35	35	35	35	35	35	35	35	35
105 W	5222	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8	30	35	35	35	35	35	35	35	35	35
	8256	CPU1: FMM2M CPU2: V2DRD	CPU1: 6 CPU2: 8	30	35	35	35	35	35	35	35	35	35
100 W	4216	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	30	35	35	35	35	35	35	35	35	35
	5215	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
	5215M	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
OF W	5215L	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
42	4215	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
	4214	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
	4214C	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35

TDP Watts	D	Heat sink model	Max memor	3.5-inch chassis 2.5-inch chassis								No-BP Chassis	
	Processo r model		y/ proces sor	12x Drives	8x Drives	4x Drive s	24x Drive s	20x Driv es	16x Drives	12x Drive s	8x Drive s	4x Drive s	N/A
	4210	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
	4208	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
	3204	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35
70 W	4209T	CPU1: JYKMM CPU2: V2DRD	CPU1: 8 CPU2: 8	35	35	35	35	35	35	35	35	35	35

Table 8. Maximum continuous operating temperature for non-fabric single processor configuration

		Heat sink model	Max memor	3.5-inc	3.5-inch chassis 2.5-inch chassis								No-BP Chassis
TDP Watts	Processor model		y/ process or	12x Drive s	8x Drive s	4x Drive s	24x Drive s	20x Drives	16x Drive s	12x Drives	8x Drives	4x Drives	N/A
205W 828 827	8280	CPU1: FMM2M	CPU1: 6	30	30	30	35	35	35	35	35	35	35
	8280L	CPU1: FMM2M	CPU1: 6	30	30	30	35	35	35	35	35	35	35
	8280M	CPU1: FMM2M	CPU1: 6	30	30	30	35	35	35	35	35	35	35
	8270	CPU1: FMM2M	CPU1: 6	30	30	30	35	35	35	35	35	35	35
	8268	CPU1: FMM2M	CPU1: 6	30	30	30	35	35	35	35	35	35	35
200 W	6254	CPU1: FMM2M	CPU1: 6	30	30	30	35	35	35	35	35	35	35
	6212U	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
165 W	8276	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	8276L	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35

	_		Max memor	3.5-inc	ch chass	sis	2.5-in	ch chass	sis				No-BP Chassis
TDP Watts	Processor model	Heat sink model	y/ process or	12x Drive s	8x Drive s	4x Drive s	24x Drive s	20x Drives	16x Drive s	12x Drives	8x Drives	4x Drives	N/A
	8276M	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	8260	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	8260L	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	8260M	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	8260C	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	6210U	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	6252	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
150 W	6248	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	6240	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	6242	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
	6244	CPU1: FMM2M	CPU1: 6	30	35	35	35	35	35	35	35	35	35
	6240C	CPU1: FMM2M	CPU1: 6	30	35	35	35	35	35	35	35	35	35
	6230	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	5220	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	5218	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
125W	5218B	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	8253	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	6238T	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	6230N	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35

			Max memor	3.5-inc	h chase	sis	2.5-in	ch chass	sis				No-BP Chassis
TDP Watts	Processor model	Heat sink model	y/ process or	12x Drive s	8x Drive s	4x Drive s	24x Drive s	20x Drives	16x Drive s	12x Drives	8x Drives	4x Drives	N/A
115 W	5217	CPU1: FMM2M	CPU1: 6	30	35	35	35	35	35	35	35	35	35
	5218T	CPU1: FMM2M	CPU1: 6	30	35	35	35	35	35	35	35	35	35
105 144	5218N	CPU1: FMM2M	CPU1: 6	30	35	35	35	35	35	35	35	35	35
105 W	5222	CPU1: FMM2M	CPU1: 6	30	35	35	35	35	35	35	35	35	35
	8256	CPU1: FMM2M	CPU1: 6	30	35	35	35	35	35	35	35	35	35
100 W	4216	CPU1: JYKMM	CPU1: 8	30	35	35	35	35	35	35	35	35	35
-	5215	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	5215M	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	5215L	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	4215	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
35 W	4214	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	4214C	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	4210	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	4208	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
	3204	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35
70 W	4209T	CPU1: JYKMM	CPU1: 8	35	35	35	35	35	35	35	35	35	35

Table 9. Configuration Restrictions with Mellanox Navi Dual Port Card with Active (Optical) connectivity

TDP Watts	3.5-inch cha	ıssis		2.5-inch cha	ıssis			No-BP Chassis
	12x HDDs	8x HDDs	4x HDDs	24x HDDs	16x HDDs	8x HDDs	4x HDDs	N/A
205 W	Not supported	23						
200 W	Not supported	23						
173 W	Not supported	Not supported	Not supported	Not supported	Not supported	24	24	28
165 W	Not supported	Not supported	Not supported	24	25	25	26	29
160 W	Not supported	Not supported	Not supported	24	25	26	26	30
150 W	Not supported	Not supported	Not supported	26	27	28	28	31
140 W	Not supported	23	25	28	29	29	30	33
135 W	Not supported	24	25	29	30	30	31	33
130 W	Not supported	24	26	30	31	31	31	34
125 W	20	25	27	30	31	32	32	35
115 W	21	27	28	32	33	34	34	>35
113 W	21	27	28	32	33	34	34	>35
105 W	22	28	30	34	35	>35	>35	>35
85 W	23	32	33	>35	>35	>35	>35	>35
70 W	25	34	>35	>35	>35	>35	>35	>35

Table 10. Configuration Restrictions with Intel Rush Creek

TDP Watts	3.5-inch cha	ssis		2.5-inch cha	2.5-inch chassis					
	12x HDDs	8x HDDs	4x HDDs	24x HDDs	16x HDDs	8x HDDs	4x HDDs	N/A		
205 W	Not supported	Not supported	Not supported	Not supported	Not supported	20	20	23		
200 W	Not supported	Not supported	Not supported	Not supported	Not supported	21	21	24		
173 W	Not supported	Not supported	Not supported	20	20	23	24	28		
165 W	Not supported	Not supported	Not supported	22	22	24	25	29		

TDP Watts	3.5-inch chas	sis		2.5-inch chas	sis			No-BP Chassis
	12x HDDs	8x HDDs	4x HDDs	24x HDDs	16x HDDs	8x HDDs	4x HDDs	N/A
160 W	Not supported	Not supported	Not supported	22	22	24	26	29
150 W	Not supported	Not supported	Not supported	24	24	26	27	30
140 W	Not supported	Not supported	Not supported	26	26	27	28	31
135 W	Not supported	Not supported	20	26	26	28	29	32
130 W	Not supported	Not supported	20	27	27	29	29	33
125 W	Not supported	Not supported	21	28	28	30	30	33
115W	Not supported	21	23	29	31	31	32	34
105 W	20	23	24	30	33	33	34	>35
85 W	24	26	27	34	>35	>35	>35	>35
70 W	25	28	29	>35	>35	>35	>35	>35

Table 11. Configuration Restrictions with Intel NVMe SSD AIC P4800X

TDP Watts	3.5-inch cha	essis		2.5-inch cha	2.5-inch chassis					
	12x HDDs	8x HDDs	4x HDDs	24x HDDs	16x HDDs	8x HDDs	4x HDDs	N/A		
205 W	Not supported									
200 W	Not supported	Not supported	Not supported	Not supported	Not supported	Not supported	Not supported	Not supported		
173 W	Not supported	20								
165 W	Not supported	20								
160 W	Not supported	25								
150 W	Not supported	Not supported	Not supported	Not supported	20	20	20	25		
140 W	Not supported	Not supported	Not supported	20	20	20	20	25		
135 W	Not supported	Not supported	Not supported	20	20	20	20	25		

TDP Watts	3.5-inch chas	sis		2.5-inch chas		No-BP Chassis		
	12x HDDs	8x HDDs	4x HDDs	24x HDDs	16x HDDs	8x HDDs	4x HDDs	N/A
130 W	Not supported	Not supported	Not supported	20	20	20	20	25
125 W	Not supported	Not supported	Not supported	20	25	25	25	30
115 W	Not supported	Not supported	Not supported	25	25	25	25	30
105 W	Not supported	Not supported	Not supported	25	25	25	25	30
85 W	Not supported	Not supported	Not supported	30	30	30	30	>35
70 W	Not supported	Not supported	Not supported	>35	>35	>35	>35	>35

Expanded operating temperature specifications

Table 12. Expanded operating temperature

Expanded operating temperature	Specifications
Continuous operation	5°C–40°C at 5% to 85% RH with maximum 29°C dew point.
	(10°C-35°C), the system can operate continuously in temperatures as low as 5°C and as high as 40°C.
	For temperatures between 35°C and 40°C, derate maximum allowable temperature by 1°C per 175 m above 950 m (1°F per 319 ft).
≤ 1% of annual operating hours	-5°C-45°C at 5% to 90% RH with maximum 29°C dew point.
	NOTE: Outside the standard operating temperature (10°C-35°C), the system can operate down to -5°C or up to 45°C for a maximum of 1% of its annual operating hours.
	For temperatures between 40°C-45°C, derate maximum allowable temperature by 1°C per 125 m above 950 m (1°F per 228 ft).

- ① | NOTE: When operating in the expanded temperature range, system performance may be impacted.
- (i) NOTE: When operating in the expanded temperature range, ambient temperature warnings may be reported in the System Event Log.

Operating temperature derating specifications

Table 13. Operating temperature

Operating temperature derating	Specifications
≤ 35°C (95°F)	Maximum temperature is reduced by 1°C/300 m (1°F/547 ft) above 950 meters (3,117 ft).
35°C-40°C (95°F-104°F)	Maximum temperature is reduced by 1° C/175 m (1° F/319 ft) above 950 meters (3,117 ft).
≥ 45°C (113°F)	Maximum temperature is reduced by 1°C/125 m (1°F/228 ft) above 950 meters (3,117 ft).

Relative humidity specifications

Table 14. Relative humidity specifications

Relative humidity	Specifications
Storage	5% to 95% RH with 33°C (91°F) maximum dew point. Atmosphere must be noncondensing always.
Operating	10% to 80% relative humidity with 29°C (84.2°F) maximum dew point.

Temperature specifications

Table 15. Temperature specifications

Temperature	Specifications
Storage	-40°C-65°C (-40°F to 149°F)
Continuous operation (for altitude less than 950 m or 3117 ft)	$10^{\circ}\text{C}-35^{\circ}\text{C}$ (50°F to 95°F) with no direct sunlight on the equipment.
Fresh air	For information about fresh air, see Expanded Operating Temperature section.
Maximum temperature gradient (operating and storage)	20°C/h (68°F/h)

(i) NOTE: Some configurations require a lower ambient temperature for more information, see the Standard operating temperature specifications.

Particulate and gaseous contamination specifications

Table 16. Particulate contamination specifications

Particulate contamination	Specifications
Air filtration	Data center air filtration as defined by ISO Class 8 per ISO 14644-1 with a 95% upper confidence limit.

- (i) NOTE: This condition applies only to data center environments. Air filtration requirements do not apply to IT equipment designed to be used outside a data center, in environments such as an office or factory floor.
- (i) NOTE: Air entering the data center must have MERV11 or MERV13 filtration.

Conductive dust

Air must be free of conductive dust, zinc whiskers, or other conductive particles.

i NOTE: This condition applies to data center and non-data center environments.

Corrosive dust Air must be free of corrosive dust.

Residual dust present in the air must have a deliquescent point less than 60% relative humidity.

(i) NOTE: This condition applies to data center and non-data center environments.

Table 17. Gaseous contamination specifications

Gaseous contamination	Specifications	
Copper coupon corrosion rate	<300 Å/month per Class G1 as defined by ANSI/ISA71.04-2013	
Silver coupon corrosion rate	<200 Å/month per Class G1 as defined by ANSI/ISA71.04-2013	

(i) NOTE: Maximum corrosive contaminant levels measured at ≤50% relative humidity.

Maximum vibration specifications

Table 18. Maximum vibration specifications

Maximum vibration	Specifications	
Operating	0.26 Grms at 5 Hz to 350 Hz (all operation orientations).	
Storage	1.88 Grms at 10 Hz to 500 Hz for 15 min (all six sides tested).	

Maximum shock specifications

Table 19. Maximum shock specifications

Maximum shock	Specifications	
Operating	24 executed shock pulses 6 G in the positive and negative x, y, z axis for up to 11 ms (four pulses on each side of the system).	
Storage	Six consecutively executed shock pulses of 71 G in the positive and negative x, y, z axes for up to 2 ms (one pulse on each side of the system).	

Maximum altitude specifications

Table 20. Maximum altitude specifications

Maximum altitude	Specifications
Operating	3048 m (10,000 ft)
Storage	12,000 m (39,370 ft)

Fresh Air Operation

Fresh Air operation restrictions

- Processors with a TDP greater than 105 W are not supported
- · Support for processors of 85 W and below without PERC restrictions
- 3.5-inch drive configuration is not supported
- 114-mm heat sink is required for the processor in CPU1 socket
- · Kerby-flat OCP is not supported
- M.2 card on DCS Mezzanine slot is not supported.
- · NVMe SSD is not supported
- · AEP DIMM and LRDIMM are not supported
- PCle cards greater than 25 W are not supported
- · H730 PERC and H330 support for 105-W processors
- No PERC restrictions for 85 W and lesser TDP processors

Documentation resources

This section provides information about the documentation resources for your system.

To view the document that is listed in the documentation resources table:

- · From the Dell EMC support site:
 - a Click the documentation link that is provided in the Location column in the table.
 - b Click the required product or product version.
 - i NOTE: To locate the product name and model, see the front of your system.
 - c On the Product Support page, click **Manuals & documents**.
- Using search engines:
 - Type the name and version of the document in the search box.

Table 21. Additional documentation resources for your system

Task	Document	Location
Setting up your system	For more information about installing and securing the system into a rack, see the Rail Installation Guide included with your rack solution. For information about setting up your system, see the Getting Started Guide document that is shipped with your system.	Dell.com/poweredgemanuals
Configuring your system	For information about the iDRAC features, configuring and logging in to iDRAC, and managing your system remotely, see the Integrated Dell Remote Access Controller User's Guide. For information about understanding Remote Access Controller Admin (RACADM) subcommands and supported RACADM interfaces, see the RACADM CLI Guide for iDRAC. For information about Redfish and its protocol, supported schema, and Redfish Eventing implemented in iDRAC, see the Redfish API Guide. For information about iDRAC property database group and object descriptions, see the Attribute Registry Guide.	Dell.com/poweredgemanuals
	For information about earlier versions of the iDRAC documents. To identify the version of iDRAC available on your system, on the iDRAC web interface, click ? > About.	Dell.com/idracmanuals
	For information about installing the operating system, see the operating system documentation.	Dell.com/operatingsystemmanuals

Task	Document	Location
Managing your system	For information about systems management software offered by Dell, see the Dell OpenManage Systems Management Overview Guide.	Dell.com/poweredgemanuals
	For information about setting up, using, and troubleshooting OpenManage, see the Dell OpenManage Server Administrator User's Guide.	Dell.com/openmanagemanuals > OpenManage Server Administrator
	For information about installing, using, and troubleshooting Dell OpenManage Essentials, see the Dell OpenManage Essentials User's Guide.	Dell.com/openmanagemanuals > OpenManage Essentials
	For information about installing and using Dell SupportAssist, see the Dell EMC SupportAssist Enterprise User's Guide.	Dell.com/serviceabilitytools
	For information about partner programs enterprise systems management, see the OpenManage Connections Enterprise Systems Management documents.	Dell.com/openmanagemanuals
Working with the Dell PowerEdge RAID controllers	For information about understanding the features of the Dell PowerEdge RAID controllers (PERC), Software RAID controllers, or BOSS card and deploying the cards, see the Storage controller documentation.	Dell.com/storagecontrollermanuals
Understanding event and error messages	For information about the event and error messages generated by the system firmware and agents that monitor system components, see the Error Code Lookup.	Dell.com/qrl
Troubleshooting your system	For information about identifying and troubleshooting the PowerEdge server issues, see the Server Troubleshooting Guide.	Dell.com/poweredgemanuals

Getting help

Topics:

- · Contacting Dell EMC
- Documentation feedback
- · Accessing system information by using QRL
- · Receiving automated support with SupportAssist
- · Recycling or End-of-Life service information

Contacting Dell EMC

Dell EMC provides several online and telephone based support and service options. If you do not have an active internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell EMC product catalog. Availability varies by country and product, and some services may not be available in your area. To contact Dell EMC for sales, technical assistance, or customer service issues:

- 1 Go to Dell.com/support/home.
- 2 Select your country from the drop-down menu on the lower right corner of the page.
- 3 For customized support:
 - a Enter your system Service Tag in the Enter your Service Tag field.
 - b Click Submit.

The support page that lists the various support categories is displayed.

- 4 For general support:
 - a Select your product category.
 - b Select your product segment.
 - c Select your product.

The support page that lists the various support categories is displayed.

- 5 For contact details of Dell EMC Global Technical Support:
 - a Click Global Technical Support.
 - b The **Contact Technical Support** page is displayed with details to call, chat, or e-mail the Dell EMC Global Technical Support team.

Documentation feedback

You can rate the documentation or write your feedback on any of our Dell EMC documentation pages and click **Send Feedback** to send your feedback.

Accessing system information by using QRL

You can use the Quick Resource Locator (QRL) located on the information tag in the front of the C6400, to access the information about the Dell EMC PowerEdge C6400.

Prerequisites

Ensure that your smartphone or tablet has the QR code scanner installed.

The QRL includes the following information about your system:

- · How-to videos
- · Reference materials, including the Installtion and Service Manual, LCD diagnostics, and mechanical overview
- · Your system service tag to quickly access your specific hardware configuration and warranty information
- · A direct link to Dell to contact technical assistance and sales teams

Steps

- 1 Go to Dell.com/qrl and navigate to your specific product or
- 2 Use your smartphone or tablet to scan the model-specific Quick Resource (QR) code on your system or in the Quick Resource Locator section

Quick Resource Locator for C6400 and C6420 systems




Figure 4. Quick Resource Locator for PowerEdge C6400 and C6420 systems

Receiving automated support with SupportAssist

Dell EMC SupportAssist is an optional Dell EMC Services offering that automates technical support for your Dell EMC server, storage, and networking devices. By installing and setting up a SupportAssist application in your IT environment, you can receive the following benefits:

- Automated issue detection SupportAssist monitors your Dell EMC devices and automatically detects hardware issues, both
 proactively and predictively.
- Automated case creation When an issue is detected, SupportAssist automatically opens a support case with Dell EMC Technical Support.
- Automated diagnostic collection SupportAssist automatically collects system state information from your devices and uploads it securely to Dell EMC. This information is used by Dell EMC Technical Support to troubleshoot the issue.
- · Proactive contact A Dell EMC Technical Support agent contacts you about the support case and helps you resolve the issue.

The available benefits vary depending on the Dell EMC Service entitlement purchased for your device. For more information about SupportAssist, go to Dell.com/supportassist.

Recycling or End-of-Life service information

Take back and recycling services are offered for this product in certain countries. If you want to dispose of system components, visit Dell.com/recyclingworldwide and select the relevant country.